

Product datasheet for AM05205RP-N

OriGene Technologies, Inc.

9620 Medical Center Drive, Ste 200 Rockville, MD 20850, US Phone: +1-888-267-4436 https://www.origene.com techsupport@origene.com EU: info-de@origene.com CN: techsupport@origene.cn

Integrin alpha E (ITGAE) Mouse Monoclonal Antibody [Clone ID: AX.14]

Product data:

Applications:

Product Type: Primary Antibodies

Clone Name: AX.14 FC

Recommended Dilution: Flow Cytometry.

Monitoring of Mucosa-associated T Lymphocytes.

Reactivity: Human Host: Mouse Isotype: lgG1

Clonality: Monoclonal

Specificity: This antibody reacts with Intestinal Lymphocytes (HML-1).

PBS containing 0.2% protein carrier and 0.08% Sodium Azide as preservative. Formulation:

Label: PE

State: Liquid purified IgG fraction

Conjugation:

Store the antibody undiluted at 2-8°C. Storage:

DO NOT FREEZE!

Stability: Shelf life: One year from despatch.

Gene Name: integrin subunit alpha E Entrez Gene 3682 Human Database Link:

P38570

Background: The CD103 antigen is a 160-130-105 kDa molecule which is expressed on mucosa-associated

> T lymphocytes and activated cells and on subset of TGF beta -1 cells. This human intra epithelial lymphocyte marker is the E integrin chain associated with the b7 subunit. CD103 antibody stains a few bone marrow cells and, rarely, peripheral blood ymphocytes. CD103 is expressed by 0.5 to 2% of resting lymphocytes in Peripheral blood and lymphoid organs.

Integrin alpha-E, Integrin alpha-IEL, HML-1 antigen, ITGAE Synonyms:







Note: Protocol: **PBMC**:

Add 10 ul of MAB/10e6 PBMC in 100 ul PBS. Mix gently and incubate for 15 minutes at 2-8°C.

Wash twice with PBS and analyze or fix with 0.5% v/v of paraformaldehyde in PBS and analyze.

WHOLE BLOOD:

Add 10 ul of MAB/100 ul of whole blood.

Mix gently and incubate for 15 minutes at room temperature (20°C).

Lyse the whole blood.

Wash once with PBS and analyze or fix with 0.5% v/v of paraformaldehyde in PBS and analyze.

See instrument manufacturers instructions for Lysed Whole Blood and Immunofluorescence analysis with a flow cytometer or microscope.